



How to see your Firmware Version from the Pulse 2 App


1 Press Menu



2 Select location



3 Choose HUB



4 Check Firmware

